


# via seating's user guide

## 38A - Adjustable Height Arm



- 1 height adjustment** - while pressing the button, use your hand to raise and lower the arm height. range 7.0" to 9.75".

**optional adjustable width bracket adds +2.25"/each side**

