


via seating's user guide

64CS - Syncro Control with Side Tension Adjustment



- 1 seat height adjustment** - adjust the seat height by lifting the paddle (located just below front, right corner of the seat cushion. proper seat height is realized when the top of your legs are somewhat parallel to the floor.
- 2 back tension adjustment** - rotate knob right to increase tilt tension. rotate knob left to decrease tilt tension.
- 3 back tilt lock (3 position)** - rotate knob right to lock in position. rotate knob left to unlock and free float. use own back tension to push against back of chair and release back from chair to find desired position.

seat and back move in a 2:1 ratio

this control is used for tall and extra tall stool kits

